





## /!\ How to equip in EP car

## **OK** Recommended Method



- Antenna receiving position is located at upper side.
- Label direction is outside.

## NG Method which receiving sensitivity become worse





- •In case of receiver's bad equipped method, receiving sensitivity become worse and receiving range become short.
- Make antenna receiving position upper side and equip apart from wining, etc.