



Compatible Devices Lists

Transmitter (TX)	•M12S
	•EXZES-ZZ
	•MT44
Reciever (RX)	•RX-472
	•RX-482
	•RX-47T



※If you do not have compatible devices  
Please Use setting by  
「MULTI SETTING GEAR」

NO.	CONTENTS	Discription	TX AUX2	Default	①	②	③	④	⑤
					Low Grip Surface	Low Grip and High Grip Surface	Feeling Like SDX-801	Feeling Like SDX-801 Evolution	High Grip Surface
1	<b>SLL-CH</b>	1:CH1 2:CH2 3:CH3	CODE 1	1:CH1 (ST)	1 : CH1 (ST)	1 : CH1 (ST)	1 : CH1 (ST)	1 : CH1 (ST)	1 : CH1 (ST)
2	<b>STRETC</b>	Stretcher Adjustment	CODE 2	30	26	29	28	28	29
3	<b>BOOST</b>	Boost Adjustment	CODE 3	30	28	28	26	33	29
4	<b>D-BAND</b>	Dead Band Adjustment	CODE 4	2	2	1	1	1	0
5	<b>MV-MID</b>	Middle Torque Adjustment	CODE 5	50	43	44	50	50	46
6	<b>MV-END</b>	End Torque Adjustment	CODE 6	30	27	30	30	30	33
7	<b>BRAKE</b>	Blake Adjustment	CODE 7	10	4	5	7	7	8
8	<b>MV-HLD</b>	Middle and End Torque Range Adjustment	CODE 8	Only by MULTI SETTING GEAR	2	2	2	2	2
9	<b>MV-FRQ</b>	Torque Adjustment During Intial- Middle, and Middle- End	CODE 9		80	80	80	80	80
10	<b>MAX-PW</b>	Max Power Adjustment	CODE 10		100	100	100	100	100